

KT45 RFID_LF
UserManual

134.2KHz 125KHz


DATE	CONTENT	MODIFIER
2015.04.08	Edit KT45 user manual	Eileen


1. Enter menu to click **LFRFID** to open the demo, seen as picture below.





2. Identify LF1 134.2KHz card. Click **OFF** to turn it to **ON ,** It will show the corresponding value on the screen when the card is within the searching range. You need click **Clear** to clear contents when the card values are filled in the screen. Click return key or **Close App** button to exit demo.





3. Identify LF2 134.2KHz card. The operation method is as same as LF1.

